

## *Quick Install Instructions*

The following will walk the installer through the installation process for our metal tiles.

Please refer to our Wall Tiles and Trim Installation Guide for instructions on using our XT-2000 Adhesive.



When installing tiles with the XT-2000 Adhesive use a 1/8 inch "V" Sawtooth Trowel. Allow the Adhesive to set for 20 to 30 minutes before installing tile.

When cutting the tiles with a wet saw be sure that the Metal Face is UP.

No tile spacers are needed, however they may be used to space tiles as to fill a given area.

Caulk using a Siliconized Acrylic Latex Caulk (available at any home construction store) that is sanded for appearance of true grout. Non-sanded Caulk can also be used for a smooth appearance of the grout.

Cut the dispensing tip of the caulk at a 45 degree angle, and place in a Caulking Gun.

Dispense caulk in the "V" groove of the tile-- filling groove completely to the surface of the tile.

Remove any large deposits of the caulk with your finger.



*Using a damp tile sponge wipe the caulk at a 45 degree angle to the tiles, use very little pressure. Rinse sponge after every stroke.*



*Continue to sponge until only a slight glaze is left on the tile and there is no grout on the tile surface.*



*Let the caulk set up for at least 12 hours, then brake the glaze with a non abrasive pan scrubber and sponge clean.*